DTC TABLE [SKYACTIV-D 1.5]

id0102q2801500

×: Applicable
—: Not applicable

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
B10A2:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Vehicle collision	—	1	Other	C	—	(See DTC B10A2:00 [SKYACTIV-D 1.5].)
P0016:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Camshaft position/ Crankshaft position correlation problem	×	1	CCM	C, R	×	(See DTC P0016:00 [SKYACTIV-D 1.5].)
P0030:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor heater control circuit range/ performance problem	×	1	A/F sensor	C	×	(See DTC P0030:00 [SKYACTIV-D 1.5].)
P0047:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Regulating solenoid valve control circuit low input	×	1	Turbo system	C, O, R	×	(See DTC P0047:00 [SKYACTIV-D 1.5].)
P0048:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Regulating solenoid valve control circuit high input	×	1	Turbo system	C, O, R	×	(See DTC P0048:00 [SKYACTIV-D 1.5].)
P0072:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Ambient temperature sensor circuit low input	—	1	Other	C, O, R	—	(See DTC P0072:00 [SKYACTIV-D 1.5].)
P0073:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Ambient temperature sensor circuit high input	—	1	Other	C, O, R	—	(See DTC P0073:00 [SKYACTIV-D 1.5].)
P007B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Boost air temperature sensor circuit range/ performance problem	×	2	Turbo system	C	×	(See DTC P007B:00 [SKYACTIV-D 1.5].)
P007C:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Boost air temperature sensor circuit low input	×	1	Turbo system	C, O, R	×	(See DTC P007C:00 [SKYACTIV-D 1.5].)
P007D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Boost air temperature sensor circuit high input	×	1	Turbo system	C, O, R	×	(See DTC P007D:00 [SKYACTIV-D 1.5].)
P0087:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Low pressure malfunction in common rail fuel pressure control system	×	1	Fuel system	C	×	(See DTC P0087:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0088:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	High pressure malfunction in common rail fuel pressure control system	×	1	Fuel system	C	×	(See DTC P0088:00 [SKYACTIV-D 1.5].)
P0089:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	High pressure malfunction in common rail fuel pressure control system	×	1	Fuel system	C	×	(See DTC P0089:00 [SKYACTIV-D 1.5].)
P0093:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel leakage from fuel pressure control system	×	1	Fuel system	C	×	(See DTC P0093:00 [SKYACTIV-D 1.5].)
P0096:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No.2 circuit range/ performance problem	×	2	Fuel system	C	×	(See DTC P0096:00 [SKYACTIV-D 1.5].)
P0097:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No.2 circuit low input	×	1	Fuel system	C, O, R	×	(See DTC P0097:00 [SKYACTIV-D 1.5].)
P0098:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No.2 circuit high input	×	1	Fuel system	C, O, R	×	(See DTC P0098:00 [SKYACTIV-D 1.5].)
P009B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure relief valve control circuit open	×	1	Fuel system	C	×	(See DTC P009B:00 [SKYACTIV-D 1.5].)
P009C:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure relief valve control circuit low input	×	1	Fuel system	C, R	×	(See DTC P009C:00 [SKYACTIV-D 1.5].)
P009D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure relief valve control circuit high input	×	1	Fuel system	C, R	×	(See DTC P009D:00 [SKYACTIV-D 1.5].)
P009E:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure relief valve malfunction (stuck close)	×	1	Fuel system	C	×	(See DTC P009E:00 [SKYACTIV-D 1.5].)
P009F:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure relief valve malfunction (stuck on)	×	1	Fuel system	C	×	(See DTC P009F:00 [SKYACTIV-D 1.5].)
P0101:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAF sensor circuit range/ performance problem	×	1	CCM	C, O	×	(See DTC P0101:00 [SKYACTIV-D 1.5].)
P0102:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAF sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0102:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0103:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAF sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0103:00 [SKYACTIV-D 1.5].)
P0106:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No. 2 circuit range/ performance problem	×	1	Turbo system	C	×	(See DTC P0106:00 [SKYACTIV-D 1.5].)
P0107:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No. 2 circuit low input	×	1	Turbo system	C, O, R	×	(See DTC P0107:00 [SKYACTIV-D 1.5].)
P0108:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	MAP sensor No. 2 circuit high input	×	1	Turbo system	C, O, R	×	(See DTC P0108:00 [SKYACTIV-D 1.5].)
P0111:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No.1 circuit range/ performance problem	×	2	CCM	C	×	(See DTC P0111:00 [SKYACTIV-D 1.5].)
P0112:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No.1 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0112:00 [SKYACTIV-D 1.5].)
P0113:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	IAT sensor No.1 circuit high input	×	1	CCM	C, O, R	×	(See DTC P0113:00 [SKYACTIV-D 1.5].)
P0116:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	ECT sensor circuit range/ performance problem	×	1	CCM	C	×	(See DTC P0116:00 [SKYACTIV-D 1.5].)
P0117:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	ECT sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0117:00 [SKYACTIV-D 1.5].)
P0118:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	ECT sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0118:00 [SKYACTIV-D 1.5].)
P0122:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve position sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0122:00 [SKYACTIV-D 1.5].)
P0123:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve position sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0123:00 [SKYACTIV-D 1.5].)
P0130:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit range/ performance problem	×	1	A/F sensor	C, O, R	×	(See DTC P0130:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0131:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit low input	×	1	A/F sensor	C, O, R	×	(See DTC P0131:00 [SKYACTIV-D 1.5].)
P0132:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit high input	×	1	A/F sensor	C, O, R	×	(See DTC P0132:00 [SKYACTIV-D 1.5].)
P0134:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	A/F sensor circuit no activity detected	×	1	A/F sensor	C	×	(See DTC P0134:00 [SKYACTIV-D 1.5].)
P0181:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel temperature sensor circuit range/ performance problem	×	2	Fuel system	C	×	(See DTC P0181:00 [SKYACTIV-D 1.5].)
P0182:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel temperature sensor circuit low input	×	1	Fuel system	C, O, R	×	(See DTC P0182:00 [SKYACTIV-D 1.5].)
P0183:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel temperature sensor circuit high input	×	1	Fuel system	C, O, R	×	(See DTC P0183:00 [SKYACTIV-D 1.5].)
P0191:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure sensor circuit range/ performance problem	×	1	Fuel system	C	×	(See DTC P0191:00 [SKYACTIV-D 1.5].)
P0192:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure sensor circuit low input	×	1	Fuel system	C, O, R	×	(See DTC P0192:00 [SKYACTIV-D 1.5].)
P0193:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel pressure sensor circuit high input	×	1	Fuel system	C, O, R	×	(See DTC P0193:00 [SKYACTIV-D 1.5].)
P0196:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil temperature sensor circuit range/ performance problem	×	2	CCM	C	×	(See DTC P0196:00 [SKYACTIV-D 1.5].)
P0197:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil temperature sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0197:00 [SKYACTIV-D 1.5].)
P0198:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil temperature sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0198:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0201:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 1 circuit open	×	1	Fuel system	C, R	×	(See DTC P0201:00 [SKYACTIV-D 1.5].)
P0202:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 2 circuit open	×	1	Fuel system	C, R	×	(See DTC P0202:00 [SKYACTIV-D 1.5].)
P0203:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 3 circuit open	×	1	Fuel system	C, R	×	(See DTC P0203:00 [SKYACTIV-D 1.5].)
P0204:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 4 circuit open	×	1	Fuel system	C, R	×	(See DTC P0204:00 [SKYACTIV-D 1.5].)
P0219:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Engine overspeed condition	—	1	Other	C	—	(See DTC P0219:00 [SKYACTIV-D 1.5].)
P0234:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Turbocharger overboost condition	—	2	Turbo system	C	×	(See DTC P0234:00 [SKYACTIV-D 1.5].)
P026A:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Charge air cooler efficiency below threshold	×	1	Turbo system	C	×	(See DTC P026A:00 [SKYACTIV-D 1.5].)
P0299:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Turbocharger underboost condition	—	2	Turbo system	C	×	(See DTC P0299:00 [SKYACTIV-D 1.5].)
P02EE:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 1 circuit: shorted to each other	×	1	Fuel system	C, R	×	(See DTC P02EE:00 [SKYACTIV-D 1.5].)
P02EF:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 2 circuit: shorted to each other	×	1	Fuel system	C, R	×	(See DTC P02EF:00 [SKYACTIV-D 1.5].)
P02F0:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 3 circuit: shorted to each other	×	1	Fuel system	C, R	×	(See DTC P02F0:00 [SKYACTIV-D 1.5].)
P02F1:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 4 circuit: shorted to each other	×	1	Fuel system	C, R	×	(See DTC P02F1:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0301:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.1 misfire	×	1	CCM	C	×	(See DTC P0301:00, P0302:00, P0303:00, P0304:00 [SKYACTIV-D 1.5].)
P0302:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.2 misfire	×	1	CCM	C	×	
P0303:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.3 misfire	×	1	CCM	C	×	
P0304:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Cylinder No.4 misfire	×	1	CCM	C	×	
P0313:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Misfire detected with low fuel	×	1	Other	C	×	(See DTC P0313:00 [SKYACTIV-D 1.5].)
P0336:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CKP sensor circuit range/ performance problem	×	2	CCM	C, R	×	(See DTC P0336:00 [SKYACTIV-D 1.5].)
P0337:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CKP sensor circuit problem	×	1	CCM	C, R	×	(See DTC P0337:00 [SKYACTIV-D 1.5].)
P0339:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CKP sensor circuit range/ performance problem	×	1	CCM	C	—	(See DTC P0339:00 [SKYACTIV-D 1.5].)
P0341:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CMP sensor circuit range/ performance problem	×	2	CCM	C, R	×	(See DTC P0341:00 [SKYACTIV-D 1.5].)
P0342:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	CMP sensor circuit problem	×	1	CCM	C, R	×	(See DTC P0342:00 [SKYACTIV-D 1.5].)
P0401:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	HP-EGR flow insufficient detected	×	2	EGR system	C	×	(See DTC P0401:00 [SKYACTIV-D 1.5].)
P0402:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	HP-EGR flow excessive detected	×	1	EGR system	C	×	(See DTC P0402:00 [SKYACTIV-D 1.5].)
P0404:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Circuit malfunction in HP-EGR control valve DC motor control system	×	1	EGR system	C, O, R	×	(See DTC P0404:00 [SKYACTIV-D 1.5].)
P0405:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	HP-EGR control valve position sensor circuit low input	×	1	EGR system	C, O, R	×	(See DTC P0405:00 [SKYACTIV-D 1.5].)
P0406:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	HP-EGR control valve position sensor circuit high input	×	1	EGR system	C, O, R	×	(See DTC P0406:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0407:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	LP-EGR control valve position sensor circuit low input	×	1	EGR system	C, O, R	×	(See DTC P0407:00 [SKYACTIV-D 1.5].)
P0408:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	LP-EGR control valve position sensor circuit high input	×	1	EGR system	C, O, R	×	(See DTC P0408:00 [SKYACTIV-D 1.5].)
P0421:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Warm up catalyst system efficiency below threshold	—	2	Catalyst	C	×	(See DTC P0421:00 [SKYACTIV-D 1.5].)
P045B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	LP-EGR control valve control: circuit malfunction	×	1	EGR system	C, O, R	×	(See DTC P045B:00 [SKYACTIV-D 1.5].)
P0471:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.1 circuit range/ performance problem	×	2	Turbo system	C	×	(See DTC P0471:00 [SKYACTIV-D 1.5].)
P0472:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.1 circuit low input	×	1	Turbo system	C, O, R	×	(See DTC P0472:00 [SKYACTIV-D 1.5].)
P0473:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.1 circuit high input	×	1	Turbo system	C, O, R	×	(See DTC P0473:00 [SKYACTIV-D 1.5].)
P0475:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust shutter valve circuit problem	×	1	EGR system	C, O, R	×	(See DTC P0475:00 [SKYACTIV-D 1.5].)
P0476:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust shutter valve circuit range/ performance problem	×	1	EGR system	C	×	(See DTC P0476:00 [SKYACTIV-D 1.5].)
P0480:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Fan control module control circuit problem	—	1	Other	C, O	—	(See DTC P0480:00 [SKYACTIV-D 1.5].)
P0488:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Duty signal error in HP-EGR control valve control system	×	1	EGR system	C	×	(See DTC P0488:00 [SKYACTIV-D 1.5].)
P048D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust shutter valve position sensor circuit low input	×	1	EGR system	C, O, R	×	(See DTC P048D:00 [SKYACTIV-D 1.5].)
P048E:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust shutter valve position sensor circuit high input	×	1	EGR system	C, O, R	×	(See DTC P048E:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P049B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	LP-EGR flow insufficient detected	×	2	EGR system	C	×	(See DTC P049B:00 [SKYACTIV-D 1.5].)
P049C:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	LP-EGR flow excessive detected	×	1	EGR system	C	×	(See DTC P049C:00 [SKYACTIV-D 1.5].)
P0500:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	VSS circuit problem	×	1	CCM	C, O, R	×	(See DTC P0500:00 [SKYACTIV-D 1.5].)
P0504:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Brake switch circuit problem	×	2	CCM	C	×	(See DTC P0504:00 [SKYACTIV-D 1.5].)
P0522:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil pressure sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P0522:00 [SKYACTIV-D 1.5].)
P0523:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil pressure sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P0523:00 [SKYACTIV-D 1.5].)
P0524:00	ON	OFF	OFF	OFF	ON	OFF	OFF	Engine oil pressure too low	×	1	CCM	C	×	(See DTC P0524:00 [SKYACTIV-D 1.5].)
P0532:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Refrigerant pressure sensor circuit low input	×	1	Other	C	×	(See DTC P0532:00 [SKYACTIV-D 1.5].)
P0533:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Refrigerant pressure sensor circuit high input	×	1	Other	C	×	(See DTC P0533:00 [SKYACTIV-D 1.5].)
P053B:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Blow-by heater relay control circuit low input	—	1	Other	C, O, R	—	(See DTC P053B:00 [SKYACTIV-D 1.5].)
P053C:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Blow-by heater relay control circuit high input	—	1	Other	C, O, R	—	(See DTC P053C:00 [SKYACTIV-D 1.5].)
P0545:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.1 circuit low input	×	1	CCM	C, O, R	×	(See DTC P0545:00 [SKYACTIV-D 1.5].)
P0546:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.1 circuit high input	×	1	CCM	C	×	(See DTC P0546:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0555:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Power brake unit vacuum sensor circuit problem	×	1	Other	C, R	—	(See DTC P0555:00 [SKYACTIV-D 1.5].)
P055F:00	ON	OFF	OFF	OFF	ON	OFF	OFF	Engine oil pressure control circuit low oil pressure	×	1	CCM	C	×	(See DTC P055F:00 [SKYACTIV-D 1.5].)
P057F:00	OFF	ON	Flash	OFF	OFF	OFF	OFF	Power system: Battery deterioration	×	1	Other	C	—	(See DTC P057F:00 [SKYACTIV-D 1.5].)
P058A:00	OFF	OFF	Flash	ON*4	OFF	OFF	OFF	Current sensor: Function malfunction	×	1	Other	C	—	(See DTC P058A:00 [SKYACTIV-D 1.5].)
P0601:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM memory check sum error	×	1	CCM	C, O, R	×	(See DTC P0601:00 [SKYACTIV-D 1.5].)
P0602:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	PCM programming error	×	1	CCM	C	—	(See DTC P0602:00 [SKYACTIV-D 1.5].)
P0605:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM memory check sum error	×	1	CCM	C	×	(See DTC P0605:00 [SKYACTIV-D 1.5].)
P0606:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM processor error	×	1	CCM	C, O, R	×	(See DTC P0606:00 [SKYACTIV-D 1.5].)
P0607:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Control module performance problem	×	1	CCM	C, O, R	×	(See DTC P0607:00 [SKYACTIV-D 1.5].)
P0610:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	PCM vehicle configuration error	×	1	CCM	C	—	(See DTC P0610:00 [SKYACTIV-D 1.5].)
P0615:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Starter relay circuit problem	—	1	Other	C	×	(See DTC P0615:00 [SKYACTIV-D 1.5].)
P062A:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Suction control valve circuit problem	×	1	Fuel system	C, R	×	(See DTC P062A:00 [SKYACTIV-D 1.5].)
P062B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM internal malfunction	×	1	Fuel system	C, O, R	×	(See DTC P062B:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0642:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply circuit low input	×	1	CCM	C	×	(See DTC P0642:00 [SKYACTIV-D 1.5].)
P0643:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply circuit high input	×	1	CCM	C	×	(See DTC P0643:00 [SKYACTIV-D 1.5].)
P0646:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	A/C relay circuit low input	—	1	Other	C	—	(See DTC P0646:00 [SKYACTIV-D 1.5].)
P0647:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	A/C relay circuit high input	—	1	Other	C	—	(See DTC P0647:00 [SKYACTIV-D 1.5].)
P0652:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply control circuit low input	×	1	CCM	C	×	(See DTC P0652:00 [SKYACTIV-D 1.5].)
P0653:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply control circuit high input	×	1	CCM	C	×	(See DTC P0653:00 [SKYACTIV-D 1.5].)
P0670:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow control module control circuit problem	—	1	CCM	C, O	×	(See DTC P0670:00 [SKYACTIV-D 1.5].)
P0671:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.1 control circuit problem	—	1	CCM	C, O	×	(See DTC P0671:00 [SKYACTIV-D 1.5].)
P0672:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.2 control circuit problem	—	1	CCM	C, O	×	(See DTC P0672:00 [SKYACTIV-D 1.5].)
P0673:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.3 control circuit problem	—	1	CCM	C, O	×	(See DTC P0673:00 [SKYACTIV-D 1.5].)
P0674:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Glow plug No.4 control circuit problem	—	1	CCM	C, O	×	(See DTC P0674:00 [SKYACTIV-D 1.5].)
P0698:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply circuit low input	×	1	CCM	C	×	(See DTC P0698:00 [SKYACTIV-D 1.5].)
P0699:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Constant voltage power supply circuit high input	×	1	CCM	C	×	(See DTC P0699:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P06B8:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Internal control module non-volatile RAM error	×	1	CCM	C	×	(See DTC P06B8:00 [SKYACTIV-D 1.5].)
P06DB:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil solenoid valve circuit low input	×	1	CCM	C, O, R	—	(See DTC P06DB:00 [SKYACTIV-D 1.5].)
P06DC:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Engine oil solenoid valve control circuit high input	×	1	CCM	C, O, R	—	(See DTC P06DC:00 [SKYACTIV-D 1.5].)
P06DD:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Engine oil pressure switch control circuit high input	—	1	Other	C	—	(See DTC P06DD:00 [SKYACTIV-D 1.5].)
P06DE:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Engine oil pressure switch control circuit low input	—	1	Other	C	—	(See DTC P06DE:00 [SKYACTIV-D 1.5].)
P0703:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Brake switch input circuit problem	×	2	CCM	C	—	(See DTC P0703:00 [SKYACTIV-D 1.5].)
P0704:00*2	ON	OFF	OFF	OFF	OFF	OFF	OFF	CPP switch input circuit problem	×	2	CCM	C	×	(See DTC P0704:00 [SKYACTIV-D 1.5].)
P07BE:00*2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Transmission indeterminate failure (failed to neutral)	×	1	Other	C	—	(See DTC P07BE:00 [SKYACTIV-D 1.5].)
P0850:00*2	ON	OFF	OFF	OFF	OFF	OFF	OFF	Neutral switch No.1 input circuit problem	×	2	CCM	C	×	(See DTC P0850:00 [SKYACTIV-D 1.5].)
P0A06:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Electric water pump control circuit low input	—	1	Other	C, O	—	(See DTC P0A06:00 [SKYACTIV-D 1.5].)
P0A07:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Electric water pump control circuit low input	—	1	Other	C, O	—	(See DTC P0A07:00 [SKYACTIV-D 1.5].)
P0A0F:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Engine failed to restart	×	1	Other	C	×	(See DTC P0A0F:00 [SKYACTIV-D 1.5].)
P0A8D:00	OFF	ON	Flash	OFF	OFF	OFF	OFF	Power supply system circuit low input	×	1	Other	C	—	(See DTC P0A8D:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P0A8F:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Power system: Low input	×	1	Other	C	—	(See DTC P0A8F:00 [SKYACTIV-D 1.5].)
P0A94:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	DC-DC converter: control circuit signal error (Without i-ELOOP) DC-DC converter (i-ELOOP): control circuit signal error (With i-ELOOP)	×	1	Other	C	—	(See DTC P0A94:00 [SKYACTIV-D 1.5].)
P0C73:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Electric water pump control: abnormal operation	—	1	Other	C	—	(See DTC P0C73:00 [SKYACTIV-D 1.5].)
P1051:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too low cylinder No.1	×	2	Fuel system	C	×	(See DTC P1051:00 [SKYACTIV-D 1.5].)
P1052:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too high cylinder No.1	×	2	Fuel system	C	×	(See DTC P1052:00 [SKYACTIV-D 1.5].)
P1053:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too low cylinder No.2	×	2	Fuel system	C	×	(See DTC P1053:00 [SKYACTIV-D 1.5].)
P1054:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too high cylinder No.2	×	2	Fuel system	C	×	(See DTC P1054:00 [SKYACTIV-D 1.5].)
P1055:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too low cylinder No.3	×	2	Fuel system	C	×	(See DTC P1055:00 [SKYACTIV-D 1.5].)
P1056:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too high cylinder No.3	×	2	Fuel system	C	×	(See DTC P1056:00 [SKYACTIV-D 1.5].)
P1057:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too low cylinder No.4	×	2	Fuel system	C	×	(See DTC P1057:00 [SKYACTIV-D 1.5].)
P1058:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Injection quantity too high cylinder No.4	×	2	Fuel system	C	×	(See DTC P1058:00 [SKYACTIV-D 1.5].)
P111A:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Engine coolant temperature is high	—	1	Other	C	—	(See DTC P111A:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P1142:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Fuel Restriction Condition	—	1	Other	C	×	(See DTC P1142:00 [SKYACTIV-D 1.5].)
P115A:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Lack of remaining fuel (output restriction)	×	1	Other	C	—	(See DTC P115A:00 [SKYACTIV-D 1.5].)
P115B:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Lack of remaining fuel (fuel injection pause)	×	1	Other	C	—	(See DTC P115B:00 [SKYACTIV-D 1.5].)
P117A:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Record of torque restriction for piston protection	—	1	Other	C	—	(See DTC P117A:00 [SKYACTIV-D 1.5].)
P1200:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injection amount learning not completed	×	1	Other	C	—	(See DTC P1200:00 [SKYACTIV-D 1.5].)
P1260:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Immobilizer system problem	—	1	Other	C	—	(See DTC P1260:00 [SKYACTIV-D 1.5].)
P1282:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Common rail control system problem	×	1	Fuel system	C	×	(See DTC P1282:00 [SKYACTIV-D 1.5].)
P1284:00	ON	ON	OFF	OFF	OFF	OFF	OFF	Fuel injector carbon deposit burn-off procedure not completed	—	1	CCM	C	×	(See DTC P1284:00 [SKYACTIV-D 1.5].)
P1329:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Common rail pressure higher than desired (engine running)	×	1	Fuel system	C	×	(See DTC P1329:00 [SKYACTIV-D 1.5].)
P1336:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	CKP sensor/ CMP sensor malfunction	—	1	CCM	C	—	(See DTC P1336:00 [SKYACTIV-D 1.5].)
P1378:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector circuit low input	×	1	Fuel system	C, R	×	(See DTC P1378:00 [SKYACTIV-D 1.5].)
P1379:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector circuit high input	×	1	Fuel system	C, R	×	(See DTC P1379:00 [SKYACTIV-D 1.5].)
P1589:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve control duty signal error	×	1	CCM	C	×	(See DTC P1589:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P1675:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector code not programmed	×	1	Fuel system	C	×	(See DTC P1675:00 [SKYACTIV-D 1.5].)
P1676:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector code mistakenly programmed	×	1	Fuel system	C	×	(See DTC P167B:00 [SKYACTIV-D 1.5].)
P167B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injection amount learning not completed in fuel injection system	×	1	Other	C	—	(See DTC P0183:00 [SKYACTIV-D 1.5].)
P176E: 00*2	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Clutch stroke sensor/starter interlock switch correlation problem	×	1	Other	C	—	(See DTC P176E:00 [SKYACTIV-D 1.5].)
P1905:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Check connector circuit low input	—	1	Other	C	—	(See DTC P1905:00 [SKYACTIV-D 1.5].)
P2002:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Diesel particulate filter function decreased	—	2	Diesel particulate filter system	C	×	(See DTC P2002:00 [SKYACTIV-D 1.5].)
P2032:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.2 circuit low input	×	1	CCM	C, O, R	×	(See DTC P2032:00 [SKYACTIV-D 1.5].)
P2033:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.2 circuit high input	×	1	CCM	C	×	(See DTC P2033:00 [SKYACTIV-D 1.5].)
P2101:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve control circuit overcurrent	×	1	CCM	C, O, R	×	(See DTC P2101:00 [SKYACTIV-D 1.5].)
P2104:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve control system: Idle air control	×	1	CCM	C	×	(See DTC P2104:00 [SKYACTIV-D 1.5].)
P2105:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Intake air shutter valve actuator control system malfunction (forced engine shutdown)	—	1	Other	C	—	(See DTC P2105:00 [SKYACTIV-D 1.5].)
P2106:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Throttle Actuator Control System - Forced Limited Power	×	1	CCM	C	×	(See DTC P2106:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P2118:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Intake shutter valve control duty signal error	×	2	CCM	C	×	(See DTC P2118:00 [SKYACTIV-D 1.5].)
P2122:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No. 1 circuit low input	×	1	CCM	C, O, R	×	(See DTC P2122:00 [SKYACTIV-D 1.5].)
P2123:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No. 1 circuit high input	×	1	CCM	C, O, R	×	(See DTC P2123:00 [SKYACTIV-D 1.5].)
P2127:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No. 2 circuit low input	×	1	CCM	C, O, R	×	(See DTC P2127:00 [SKYACTIV-D 1.5].)
P2128:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No. 2 circuit high input	×	1	CCM	C, O, R	×	(See DTC P2128:00 [SKYACTIV-D 1.5].)
P2138:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	APP sensor No. 1/No.2 correlation problem	×	1	CCM	C	×	(See DTC P2138:00 [SKYACTIV-D 1.5].)
P213B:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	LP-EGR valve control: high duty malfunction	×	1	EGR system	C	×	(See DTC P213B:00 [SKYACTIV-D 1.5].)
P2146:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 1 and No.4 open	×	1	Fuel system	C, R	×	(See DTC P2146:00 [SKYACTIV-D 1.5].)
P2147:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 1 and No.4 circuit low input	×	1	Fuel system	C, R	×	(See DTC P2147:00 [SKYACTIV-D 1.5].)
P2148:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 1 and No.4 circuit high input	×	1	Fuel system	C, R	×	(See DTC P2148:00 [SKYACTIV-D 1.5].)
P2149:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 2 and No.3 circuit open	×	1	Fuel system	C, R	×	(See DTC P2149:00 [SKYACTIV-D 1.5].)
P2150:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 2 and No.3 circuit low input	×	1	Fuel system	C, R	×	(See DTC P2150:00 [SKYACTIV-D 1.5].)
P2151:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Fuel injector No. 2 and No.3 circuit high input	×	1	Fuel system	C, R	×	(See DTC P2151:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P2227:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	BARO sensor circuit range/ performance problem	×	1	CCM	C	×	(See DTC P2227:00 [SKYACTIV-D 1.5].)
P2228:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	BARO sensor circuit low input	×	1	CCM	C, O, R	×	(See DTC P2228:00 [SKYACTIV-D 1.5].)
P2229:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	BARO sensor circuit high input	×	1	CCM	C, O, R	×	(See DTC P2229:00 [SKYACTIV-D 1.5].)
P2263:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Turbocharger solenoid valve control circuit range/ performance problem	×	2	Turbo system	C	×	(See DTC P2263:00 [SKYACTIV-D 1.5].)
P2299:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Accelerator pedal: spring back malfunction	—	1	Other	C	—	(See DTC P2299:00 [SKYACTIV-D 1.5].)
P242C:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.3 circuit low input	×	1	CCM	C, O, R	×	(See DTC P242C:00 [SKYACTIV-D 1.5].)
P242D:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.3 circuit high input	×	1	CCM	C	×	(See DTC P242D:00 [SKYACTIV-D 1.5].)
P242F:00	ON	OFF	OFF	OFF	OFF	OFF	Flash	Diesel particulate filter excess accumulation (exceeded acceptable amount)	×	1	CCM	C	×	(See DTC P242F:00 [SKYACTIV-D 1.5].)
P243C:00	OFF	OFF	OFF	OFF	OFF	OFF	Flash	Abnormal diesel particulate filter regeneration interval short distance	—	1	Other	C	×	(See DTC P243C:00 [SKYACTIV-D 1.5].)
P244A:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.2 range/ performance problem	×	1	Diesel particulate filter system	C	×	(See DTC P244A:00 [SKYACTIV-D 1.5].)
P2452:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Signal malfunction in exhaust gas pressure sensor No.2	—	1	Diesel particulate filter system	C	—	(See DTC P2452:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P2454:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.2 circuit low input	×	1	Diesel particulate filter system	C, O, R	×	(See DTC P2454:00 [SKYACTIV-D 1.5].)
P2455:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas pressure sensor No.2 circuit high input	×	1	Diesel particulate filter system	C, O, R	×	(See DTC P2455:00 [SKYACTIV-D 1.5].)
P2456:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Characteristic malfunction in exhaust gas pressure sensor No.2	×	1	Diesel particulate filter system	C	×	(See DTC P2456:00 [SKYACTIV-D 1.5].)
P2458:00	OFF	OFF	OFF	OFF	OFF	OFF	Flash	Diesel particulate filter excess accumulation (mid)	×	1	Other	C	—	(See DTC P2458:00 [SKYACTIV-D 1.5].)
P2459:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Abnormal diesel particulate filter regeneration interval short distance*5	—	1	Other	C	×	(See DTC P2459:00 [SKYACTIV-D 1.5].)
P2463:00	ON	OFF	OFF	OFF	OFF	OFF	Flash	Diesel particulate filter excess accumulation (large)	×	1	CCM	C	×	(See DTC P2463:00 [SKYACTIV-D 1.5].)
P246C:00	OFF	OFF	OFF	OFF	ON	OFF	OFF	Engine oil dilution, oil pressure decreased	—	1	Other	C	—	(See DTC P246C:00 [SKYACTIV-D 1.5].)
P2470:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.4 circuit low input	×	1	CCM	C, O, R	×	(See DTC P2470:00 [SKYACTIV-D 1.5].)
P2471:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Exhaust gas temperature sensor No.4 circuit high input	×	1	CCM	C	×	(See DTC P2471:00 [SKYACTIV-D 1.5].)
P2502:00	OFF	OFF	Flash	ON*4	OFF	OFF	OFF	Generator system: Malfunction in voltage generated by generator	×	1	Other	C	—	(See DTC P2502:00 [SKYACTIV-D 1.5].)
P2503:00	OFF	OFF	Flash	ON*4	OFF	OFF	OFF	Generator system: Voltage generated by generator is low	×	1	Other	C	—	(See DTC P2503:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P2504:00	OFF	OFF	Flash	ON*4	OFF	OFF	OFF	Generator system: Voltage generated by generator is high	×	1	Other	C	—	(See DTC P2504:00 [SKYACTIV-D 1.5].)
P2507:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	PCM battery voltage low input	×	1	CCM	C	×	(See DTC P2507:00 [SKYACTIV-D 1.5].)
P250A:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Engine oil level signal: engine oil level sensor malfunction	—	1	Other	C	—	(See DTC P250A:00 [SKYACTIV-D 1.5].)
P250C:00	OFF	OFF	OFF	OFF	ON	OFF	OFF	Engine oil level sensor power supply circuit malfunction	—	1	Other	C	—	(See DTC P250C:00 [SKYACTIV-D 1.5].)
P250F:00	OFF	OFF	OFF	OFF	OFF	ON	OFF	Engine oil level signal: engine oil level low	—	1	Other	C	—	(See DTC P250F:00 [SKYACTIV-D 1.5].)
P252F:00	OFF	OFF	OFF	OFF	OFF	ON	OFF	Engine oil level too high	—	1	Other	C	—	(See DTC P252F:00 [SKYACTIV-D 1.5].)
P253F:00	OFF	OFF	OFF	OFF	ON	OFF	OFF	Engine oil deteriorated	—	1	Other	C	—	(See DTC P253F:00 [SKYACTIV-D 1.5].)
P2564:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Actuator position sensor circuit low input	×	1	Turbo system	C, R	×	(See DTC P2564:00 [SKYACTIV-D 1.5].)
P2565:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Actuator position sensor circuit high input	×	1	Turbo system	C, O, R	×	(See DTC P2565:00 [SKYACTIV-D 1.5].)
P2579:00	OFF	ON	OFF	OFF	OFF	OFF	OFF	Speed sensor assy. (turbocharger) range/ performance problem	×	1	Turbo system	C	—	(See DTC P2579:00 [SKYACTIV-D 1.5].)
P2580:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Speed sensor assy. (turbocharger) circuit low input	×	1	Turbo system	C	×	(See DTC P2580:00 [SKYACTIV-D 1.5].)
P2581:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Speed sensor assy. (turbocharger) circuit high input	×	1	Turbo system	C	×	(See DTC P2581:00 [SKYACTIV-D 1.5].)
P2610:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Instrument cluster internal engine off timer performance problem	×	2	CCM	C	×	(See DTC P2610:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
P2681:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Circuit malfunction in coolant control valve control system	×	1	CCM	C, O, R	×	(See DTC P2681:00 [SKYACTIV-D 1.5].)
P2682:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Coolant control valve position sensor circuit low input	—	1	CCM	C, O, R	×	(See DTC P2682:00 [SKYACTIV-D 1.5].)
P2683:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Coolant control valve position sensor circuit high input	—	1	CCM	C, O, R	×	(See DTC P2683:00 [SKYACTIV-D 1.5].)
P26A3:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Coolant control valve control: high duty malfunction	×	1	CCM	C, O	×	(See DTC P26A3:00 [SKYACTIV-D 1.5].)
P2A00:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	Atmosphere learning malfunction in A/F sensor circuit	×	1	A/F sensor	C	×	(See DTC P2A00:00 [SKYACTIV-D 1.5].)
U0073:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CAN system communication error (HS CAN)	—	—	Other	C, O, R	—	(See DTC U0073:00, U0101:00, U0121:00, U0131:00, U0140:00, U0151:00, U0155:00, U0214:00, U0235:00 [SKYACTIV-D 1.5].)
U0074:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CAN system communication error (local CAN between PCM and TCM)	—	—	Other	C	—	(See DTC U0074:00 [SKYACTIV-D 1.5].)
U0101:00	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication: communication error to TCM	×	1	CCM	C	×	(See DTC U0073:00, U0101:00, U0121:00, U0131:00, U0140:00, U0151:00, U0155:00, U0214:00, U0235:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
U0106:00	ON	OFF	OFF	OFF	OFF	OFF	OFF	LIN communication system: glow plug control module information communication error with PCM	×	1	CCM	C, O	×	(See DTC U0106:00 [SKYACTIV-D 1.5].)
U0121:00	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication: communication error to DSC HU/CM	×	1	CCM	C	×	(See DTC U0073:00, U0101:00, U0121:00, U0131:00, U0140:00, U0151:00, U0155:00, U0214:00, U0235:00 [SKYACTIV-D 1.5].)
U0131:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication: communication error to EPS control module	—	1	Other	C	—	
U0140:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication: communication error to body control module (BCM)	—	1	Other	C	—	
U0151:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication: communication error to SAS control module	—	1	Other	C	—	
U0155:00	ON	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication: communication error to instrument cluster	×	1	CCM	C	×	
U0214:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	CAN communication: communication error to start stop unit	—	1	Other	C	—	
U0235:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	CAN communication: communication error to laser sensor	—	1	Other	C	—	

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
U0298:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	CAN/LIN communication system: DC-DC converter information communication error with body control module (BCM) (without i-ELOOP) CAN communication: communication error to DC-DC converter (i-ELOOP) (with i-ELOOP)	×	1	Other	C	—	(See DTC U0298:00 [SKYACTIV-D 1.5].)
U0302:00 *3	ON	OFF	OFF	OFF	OFF	OFF	OFF	TCM processor error	×	1	CCM	C	×	(See DTC U0302:00 [SKYACTIV-D 1.5].)
U0315:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	DSC HU/CM error	—	1	Other	C	—	(See DTC U0315:00 [SKYACTIV-D 1.5].)
U0320:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	EPS control module error	—	1	Other	C	—	(See DTC U0320:00 [SKYACTIV-D 1.5].)
U0323:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Instrument cluster error	—	1	Other	C	—	(See DTC U0323:00 [SKYACTIV-D 1.5].)
U0336:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	SAS control module error	—	1	Other	C	—	(See DTC U0336:00 [SKYACTIV-D 1.5].)
U0338:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Start stop unit error	—	1	Other	C	—	(See DTC U0338:00 [SKYACTIV-D 1.5].)
U0433:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Abnormal message from laser sensor	×	1	Other	C	—	(See DTC U0433:00 [SKYACTIV-D 1.5].)
U0599:00	OFF	OFF	Flash	OFF	OFF	OFF	OFF	Invalid data received from DC-DC converter	×	1	Other	C	—	(See DTC U0599:00 [SKYACTIV-D 1.5].)

DTC No.	Check engine light	Master warning light	i-stop warning light (amber)	Charging system warning light	Engine oil warning light	Wrench indicator light	Diesel particulate filter indicator light	Condition	Fail-safe function	Drive cycle	Monitor item	Self test type *1	Memory function	Page
U1007:00	OFF	ON	Flash	ON	OFF	OFF	OFF	CAN/LIN communication system: current sensor information communication error with body control module (BCM)	—	—	Other	C	—	(See DTC U1007:00 [SKYACTIV-D 1.5].)
U1100:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	LIN communication: communication error to engine oil level sensor	—	1	Other	C	—	(See DTC U1100:00 [SKYACTIV-D 1.5].)
U2300:00	OFF	OFF	OFF	OFF	OFF	OFF	OFF	Global central configuration error	—	1	Other	C	—	(See DTC U2300:00 [SKYACTIV-D 1.5].)
U3000:41	OFF	OFF	OFF	OFF	OFF	OFF	OFF	PCM processor error	—	1	Other	C	—	(See DTC U3000:41 [SKYACTIV-D 1.5].)

*1 : C: CMDTC self test, O: KOEO self test, R: KOER self test
*2 : MTX
*3 : ATX
*4 : Displays a message related to a charge system malfunction in the display. (With center display)
*5 : Glow indicator light flashes