DTC P0C73:00 [SKYACTIV-D 1.5]

id0102q2852400

DTC P0C73:00	Circuit malfunction in LP-EGR control valve DC motor control system
DETECTION CONDITION	• When the following monitoring conditions are met, the PCM terminal 1CP voltage is approx. **6.0 V or more** for a continuous **1 s**: **MONITORING CONDITIONS** — Engine speed: Is the engine speed in the span of the **3 to 6 s** following the **3 s** from when **700 rpm** or more is reached. — Electric water pump control duty value: **10—20%** — Battery voltage: **8—16V** — The following DTCs are not detected: • IAT sensor No.1: P0112:00, P0113:00 • Electric water pump circuit: P0A06:00, P0A07:00 **Diagnostic support note** • This is a continuous monitor (CCM). • The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. • FREEZE FRAME DATA/Snapshot data is available. • DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	• Not applicable
POSSIBLE CAUSE	• Electric water pump internal circuit malfunction • PCM internal circuit malfunction
SYSTEM WIRING DIAGRAM	• Not applicable

Diagnostic Procedure

STEP	INSPECTION		ACTION
1	**RECORD VEHICLE STATUS WHEN DTC WAS DETECTED TO UTILIZE WITH REPEATABILITY VERIFICATION** **Note** • Recording can be facilitated using the screen capture of the PC function. • Record the freeze frame data/snap shot data.	—	Go to the next step.
2	**VERIFY RELATED REPAIR INFORMATION AVAILABILITY** • Verify related Service Bulletins and/or on-line repair information availability. • Is any related repair information available?	Yes	Perform repair or diagnosis according to the available repair information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	**VERIFY RELATED PENDING CODE AND/OR DTC** • Switch the ignition off, then ON (engine off). • Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See OBD ON-BOARD SYSTEM READINESS TEST [SKYACTIV-D 1.5].) • Are any other PENDING CODEs and/or DTCs present?	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
4	**INSPECT ELECTRIC WATER PUMP** • Inspect the electric water pump. (See ELECTRIC WATER PUMP INSPECTION [SKYACTIV-D 1.5].) • Is there any malfunction**?**	Yes	Replace the electric water pump, then go to the next step. (See ELECTRIC WATER PUMP REMOVAL/ INSTALLATION [SKYACTIV-D 1.5].)
		No	Go to the next step.

STEP	INSPECTION		ACTION
5	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See CLEARING DTC [SKYACTIV-D 1.5].) • Perform the KOEO self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 1.5].) • Is the same DTC present?	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) Go to the next step.
		No	Go to the next step.
6	**VERIFY AFTER REPAIR PROCEDURE** • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	DTC troubleshooting completed.