CLEARING DTC [SKYACTIV-D 1.5]

id0102q2865400

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “Modules”.
   (3) Select “PCM”.
3. Then, select the “Retrieve CMDTCs” and perform procedures according to directions on the M-MDS screen.
4. Verify the DTC according to the directions on the M-MDS screen.
5. Press the clear button on the DTC screen to clear the DTC.
6. Verify that no DTCs are displayed.
7. Switch the ignition off.