NO.11 ENGINE STALLS-AFTER START/AT IDLE [SKYACTIV-D 1.5]

id0103q2897800

11	ENGINE STALLS-AFTER START/AT IDLE
DESCRIPTION	• Stalling occurs if vehicle is left idling under no load. • Stalling occurs when load (electric, A/C) is applied during idling. • Stalling occurs if the accelerator pedal is depressed from an idling condition when accelerating from a stop.
POSSIBLE CAUSE	• PCM DTC is stored. • A/C relay malfunction • ECT sensor malfunction • Fuel injection system malfunction — Fuel leakage from fuel system — Air suction in fuel system — Common rail malfunction — Supply pump malfunction — Suction control valve malfunction — Fuel injector malfunction — Fuel pressure relief valve malfunction • Poor fuel quality • Mechanical (engine) malfunction — Large mechanical resistance (such as A/C compressor) — Improper engine compression — Improper valve timing — Engine oil malfunction (oil working up or down) • ATX malfunction (ATX) **Warning** **• The following troubleshooting flow chart contains the fuel system diagnosis and repair procedures. Read the following warnings before performing the fuel system services:** **— Always keep sparks and flames away from fuel. Fuel can be easily ignited which could cause serious injury or death, and damage to equipment.** **— Fuel line spills and leakage from the pressurized fuel system are dangerous. Fuel can ignite and cause serious injury or death, and damage to property and facilities. Fuel can also irritate skin and eyes. To prevent this, always complete the "Fuel Line Safety Procedure", while referring to the "BEFORE SERVICE PRECAUTION". (See BEFORE SERVICE PRECAUTION [SKYACTIV-D 1.5].)** **— Fuel is highly flammable and dangerous. Fuel line spills and leakage can cause serious injury or death, and damage to equipment. When installing the fuel hose, always refer to the "AFTER SERVICE PRECAUTION" and perform the "Fuel Hose Installation Procedure". (See AFTER SERVICE PRECAUTION [SKYACTIV-D 1.5].)**

Diagnostic Procedure

STEP	INSPECTION	RESULTS	ACTION
1	**VERIFY PCM DTC** • Retrieve PCM DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 1.5].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 1.5].)
		No	Go to the next step.
2	**INSPECT A/C RELAY** • Switch the ignition off. • Remove the A/C relay. • Inspect the A/C relay. (See RELAY INSPECTION.) • Is the A/C relay normal?	Yes	Go to the next step.
		No	Replace the A/C relay, then go to Step 12.
3	**INSPECT ECT SENSOR** • Inspect the ECT sensor. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR INSPECTION [SKYACTIV-D 1.5].) • Is the ECT sensor normal?	Yes	Go to the next step.
		No	Replace the ECT sensor, then go to Step 12. (See ENGINE COOLANT TEMPERATURE (ECT) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)

STEP	INSPECTION	RESULTS	ACTION
4	**INSPECT FOR FUEL LEAKAGE OR AIR SUCTION IN FUEL SYSTEM** • Visually inspect the following: — Fuel leakage from the fuel tank, fuel pump, hose, pipe, fuel injector, supply pump, common rail — Cracking and damage in fuel hose and pipe — Clamp installation condition for each hose and pipe — Fuel pipe securing condition due to deterioration such as rubber of clamp • Are all items normal?	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results, then go to Step 12.
5	**INSPECT FUEL INJECTION RELATED PARTS** • Inspect the following parts: — Common rail (See COMMON RAIL INSPECTION [SKYACTIV-D 1.5].) — Supply pump (See SUPPLY PUMP INSPECTION [SKYACTIV-D 1.5].) — Suction control valve (See SUCTION CONTROL VALVE INSPECTION [SKYACTIV-D 1.5].) — Fuel injector (See FUEL INJECTOR INSPECTION [SKYACTIV-D 1.5].) — Fuel pressure relief valve (See FUEL PRESSURE RELIEF VALVE INSPECTION [SKYACTIV-D 1.5].) • Are all items normal?	Yes	Go to the next step.
		No	Repair or replace the malfunctioning part according to the inspection results, then go to Step 12.
6	**INSPECT FOR MALFUNCTION DUE TO POOR FUEL** • Replace the fuel. (See FUEL DRAINING PROCEDURE [SKYACTIV-D 1.5].) • Does the symptom disappear?	Yes	Advise the customer as to the change in the fuel used.
		No	Remove the accumulated matter in the cylinder head using the following procedure, then go to the next step. • Carbon remover • Overhauling
7	**DETERMINE IF MALFUNCTION IS DUE TO EXCESSIVE ENGINE SPEED RESISTANCE** • Rotate the crankshaft pulley lock bolt clockwise using a wrench. (See FRONT OIL SEAL REPLACEMENT [SKYACTIV-D 1.5].) • Can bolts be rotated?	Yes	ATX: • Go to Step 9. MTX: • Go to Step 10.
		No	Go to the next step.
8	**INSPECT FOR MALFUNCTION DUE TO EXCESSIVE MECHANICAL RESISTANCE OF ENGINE ACCESSORIES** • Remove all drive belts from engine accessories. (See DRIVE BELT REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) **Caution** **• Do not run the engine for long periods with the drive belts of engine accessories removed. Otherwise the engine could be damaged from overheating.** • Start the engine. • Is cranking possible? (Does the engine start?)	Yes	Repair or replace the malfunctioning part according to the inspection results, then go to Step 12. (Large mechanical resistance in engine accessories such as the A/C compressor.)
		No	ATX: • Go to the next step. MTX: • Go to Step 10.

STEP	INSPECTION	RESULTS	ACTION
9	**VERIFY ATX DTC** • Retrieve any DTCs using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST MODE [TCM (EW6A-EL)].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (EW6A-EL)].)
		No	Go to the next step.
10	**INSPECT ENGINE COMPRESSION** • Inspect the engine compression. (See COMPRESSION INSPECTION [SKYACTIV-D 1.5].) • Are compression pressures within specification? **Specification:** • Compression — Standard: **2150—2350 kPa {21.93—23.96 kgf/cm^2, 311.9—340.8 psi} (200 rpm)** — Minimum: **1800 kPa {18.35 kgf/cm^2, 261.1 psi} (200 rpm)** — Maximum difference between cylinders: **150 kPa {1.53 kgf/cm^2, 21.8 psi} (200 rpm)**	Yes	Go to Step 12.
		No	Go to the next step.
11	**INSPECT FOR MALFUNCTION DUE TO DEVIATED VALVE TIMING** • Inspect the valve timing (timing chain installation condition). (See TIMING CHAIN REMOVAL/ INSTALLATION [SKYACTIV-D 1.5].) • Is the valve timing normal?	Yes	Inspect for the following engine internal parts: • Cylinder • Piston ring • Intake valve • Exhaust valve • Such as cylinder head gasket Repair or replace the malfunctioning part according to the inspection results, then go to the next step.
		No	Adjust the valve timing to the correct timing, then go to the next step.
12	Verify the test results. • If normal, return to the diagnostic index to service any additional symptoms. (See SYMPTOM DIAGNOSTIC INDEX [SKYACTIV-D 1.5].) • If a malfunction remains, inspect the related Service Information and perform the repair or diagnosis. — If the vehicle is repaired, troubleshooting is completed. — If the vehicle is not repaired or additional diagnostic information is not available, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)		