DRIVE BELT AUTO TENSIONER REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0110q2362500


Warning

- **A hot engine can cause severe burns. Turn off the engine and wait until it is cool before servicing.**


Caution

- **If the rubber part of the drive belt auto tensioner is damaged by a screwdriver or other tool, oil in the hydraulic pressure unit could leak and the tensioner may not operate normally. Be careful not to damage the rubber part of the drive belt auto tensioner.**

1. Remove the engine cover. (See ENGINE COVER REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
2. Remove the drive belt. (See DRIVE BELT REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
3. Remove the bolts shown in the figure and set the wiring harness aside.
4. Remove in the order indicated in the table.
5. Install in the reverse order of removal.




am2zzw00012297



am2zzw00010088

1	Drive belt auto tensioner (See Drive Belt Auto Tensioner Installation Note.)



am2zzw00010089

Drive Belt Auto Tensioner Installation Note

Caution

- **To allow the drive belt auto tensioner to function correctly, always bleed the air from the drive belt auto tensioner using the following procedure after assembling the drive belt auto tensioner.**


1. Install the drive belt auto tensioner to the engine.

Tightening torque
47—57 N·m {4.8—5.8 kgf·m, 35—42 ft·lbf}

Caution
- **To prevent damage to the drive belt auto tensioner, do not apply excessive torque after the tensioner moves full-stroke.**

2. Insert the wrench onto the cast hexagon on the drive belt auto tensioner, move the drive belt auto tensioner up and down at full-stroke three times to bleed the air.

Note
- By moving the drive belt auto tensioner up and down full-stroke three times, the piston inside the tensioner moves to bleed the air.



am2zzw00012298