VALVE, VALVE SPRING, VALVE SEAL, VALVE GUIDE [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0110q3001300

Purpose, Function

Valve

- The intake valve is pressed down by the cam, the intake air passage is opened, and air is introduced into the cylinder.
- The exhaust valve is pressed down by the cam, the exhaust air passage is opened, and combustion gas is exhausted from the cylinder.

Valve spring

- The valve spring adheres the valve to the valve seat by pulling up the valve by spring force, and air tightness in the combustion chamber is maintained.

Valve seal


- The valve seal prevents engine oil from entering combustion chamber through the valve guide, and engine oil consumption is suppressed.

Valve guide

- The valve guide maintains the valve stem to open and close the valve smoothly.
- The valve guide cools the valve by transmitting valve heat to the cylinder head.

Construction

- The valve, valve spring, valve seal, and valve guide are assembled to the cylinder head.



am3uun00001861

- The sliding resistance has been reduced by setting the valve spring load to the required minimum.
- The intake valve and exhaust valve are subjected to a nitriding treatment to enhance wear resistance.
- Unequal pitch valve spring has been adopted. In addition, the upper diameter is smaller compared to the bottom diameter.
- The valve guide is made of sintered alloy with excellent wear resistance.