DRIVE BELT REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0110q3801600


Warning
- **A hot engine can cause severe burns. Turn off the engine and wait until it is cool before servicing.**

Generator Drive Belt Removal/Installation

Caution
- **To prevent damage to the drive belt auto tensioner, do not apply excessive torque after the tensioner moves full-stroke.**

Note
- Remove/install the generator drive belt from above the vehicle.

1. Insert a wrench onto the cast hexagon on the drive belt auto tensioner and release the tension by slowly turning in the direction shown in the figure.
2. Remove the generator drive belt.
3. Install the generator drive belt.
4. Rotate the crankshaft pulley clockwise approx. halfway and verify that the generator drive belt is installed correctly.
   - If the rib of the drive belt and the groove of each pulley are not aligned, remove the drive belt and re-install it.
5. Verify that the indicator part of the cast hexagon on the drive belt auto tensioner is within the normal range.(See DRIVE BELT INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)




am3zzw00014690


Water Pump Drive Belt

Note
- Remove/install the water pump drive belt from the underside of the vehicle.

Removal
1. Remove the generator drive belt. (See Generator Drive Belt Removal/Installation.)
2. Remove the front splash shield (RH). (See SPLASH SHIELD REMOVAL/INSTALLATION.)
3. Apply a clean cloth to the water pump drive belt as shown in the figure.


am3uuw00008888

4. Pull the cloth in the direction of the arrow and rotate the crankshaft pulley clockwise.



am3uuw00008889

Caution
- **To prevent damaging the drive belt, do not stop rotating the crankshaft pulley while performing the removal procedure (with inserted cloth between drive belt and water pump pulley).**

Note
- The rib of the drive belt can be slid from the groove of the water pump pulley by rotating the crankshaft pulley while pulling the cloth in the direction of the arrow.

5. Remove the water pump drive belt.

Installation
1. Set one side of the water pump drive belt into the groove of the crankshaft pulley.
2. Set the other side of the water pump drive belt into the groove of the water pump pulley with the smaller circumference.




am3uuw00008890

Caution
- **Be careful not to get a finger caught in between the drive belt and pulley when performing the following procedure.**
- **Wearing gloves could result in fingers getting caught between the drive belt and pulley. Do not wear cotton gloves when performing the procedure.**

3. Press the drive belt up from the smaller circumference pulley into the groove of the larger circumference pulley, and rotate the crankshaft pulley clockwise.

Caution
- **To prevent damaging the drive belt, do not stop rotation of the crankshaft pulley while pressing the drive belt up from the height difference of the water pump pulley to the groove of the pulley.**

4. After drive belt installation, rotate the crankshaft pulley clockwise approx. halfway and verify that the water pump drive belt is installed correctly.
   - If the rib of the drive belt and the groove of the pulley are not aligned, remove the drive belt and re-install it.
5. Install the front splash shield (RH). (See SPLASH SHIELD REMOVAL/INSTALLATION.)
6. Install the generator drive belt. (See Generator Drive Belt Removal/Installation.)


am3uuw00008891