OIL PRESSURE INSPECTION [SKYACTIV-D 1.5]

id0111q2800300

1. Connect the M-MDS to the DLC-2.
2. Start the engine and warm it up.
3. Select the engine hydraulic pressure (PID: EOP) and the engine speed (PID: RPM) using the M-MDS data monitor function.
4. Verify the engine hydraulic pressure (PID: EOP) value while the engine maintains a constant speed.
   - If not within the specification, determine the malfunctioning location referring to the following DTCs “Possible Cause” and repair or replace the applicable part.
     — P0524:00 (Engine oil pressure too low)
     — P055F:00 (Engine oil pressure control circuit low oil pressure)
     — P06DD:00 (Engine oil pressure switch control circuit high input)
     — P06DE:00 (Engine oil pressure switch control circuit low input)

   Note
   - The oil pressure can vary with oil viscosity, temperature, and engine speed.

   Oil pressure (reference value) [oil temperature: 80—90 °C {176—194 °F}, coolant temperature: 80—90 °C {176—194 °F}]

   Lo: 110—175 kPa {1.13—1.78 kgf/cm^2, 16.0—25.3 psi} [1,500 rpm]

   Hi: 300—430 kPa {3.06—4.38 kgf/cm^2, 43.6—62.3 psi} [3,000 rpm]