OIL FILTER [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0111q3002200

Purpose, Function

- Engine oil is filtered by passing engine oil through the oil filter element.

Construction

- The oil filter is located on the right side surface of the cylinder block.
- A spin-on type (full-flow type) oil filter has been adopted.