4. The oil passage to the nozzle is closed and the injection of engine oil stops.

