ENGINE OIL SOLENOID VALVE [SKYACTIV-G 1.5 (WITH 4-2-1 EXHAUST SYSTEM)]

id0111q30027q5

Purpose, Function

- The engine oil solenoid valve switches the hydraulic transmission passage in accordance with the driving conditions and the oil pump drive resistance is reduced by controlling oil pump discharging pressure in two steps.