ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0111q3002900

Engine Oil Solenoid Valve Operation Inspection

1. Remove the engine oil solenoid valve. (See ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Verify that the battery is fully charged. (See BATTERY INSPECTION.)
3. Connect the battery to the engine oil solenoid valve connector (2 terminals) as shown in the figure.
4. Verify that there is an operation sound from the engine oil solenoid valve when applying battery voltage between engine oil solenoid valve connector terminals A and B.
   - If the operation sound cannot be heard, replace the engine oil solenoid valve.

   Note
   - A click sound is heard when the engine oil solenoid valve operates normally.

5. Install the engine oil solenoid valve. (See ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)



am2zzw00012315