ENGINE COOLANT PROTECTION INSPECTION [SKYACTIV-D 1.5]

id0112q2800400


1. Measure the engine coolant temperature and specific gravity using a thermometer and a hydrometer.

Caution

- **Use engine coolant at a concentration that meets the environmental conditions in which the vehicle is driven, otherwise engine damage could occur.**
- **The engine has aluminum parts and must be protected by an ethylene-glycol-based coolant to prevent corrosion and freezing.**
- **Do not use coolants containing Alcohol, Methanol, Borate or Silicate. These coolants could damage the cooling system.**
- **Use only soft (demineralized) water in the coolant mixture. Water that contains minerals will cut down on the coolant's effectiveness.**
- **Engine coolant damages paint. If engine coolant does get on a painted surface, rinse it off quickly.**


Note

- If the "FL22" mark is shown on or near the cooling system cap, use FL22 type engine coolant.
- FL22 type engine coolant is shipped as a diluted solution. Use the solution as is when replacing coolant.



am2zzw00001691

2. Determine the engine coolant protection level by referring to the graph shown in the figure.
   - If the engine coolant protection level is not correct, add water or engine coolant.



am2zzw00001692