THERMOSTAT INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0112q3801300

1. Remove the thermostat. (See THERMOSTAT REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Visually check that the thermostat valve is closed.
3. Place the thermostat in water.

Warning
- **During inspection, the thermostat and water are extremely hot and can cause severe burns. Do not touch the thermostat and water.**

4. Heat the water and check the following.
   - Opening temperature and valve lift
     — If there is a malfunction, replace the thermostat.

Thermostat initial-opening temperature
86.5—89.5 °C {188—193 °F}

Thermostat full-open temperature
100 °C {212 °F}

Thermostat full-open lift
More than 8.5 mm {0.33 in}