AIR CLEANER ELEMENT INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0113q1800800

1. Remove the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Inspect the following items:
   - Has the replacement interval past?
   - Is the air cleaner element soiled, damaged, or bent?
   - Are the air cleaner case and the air cleaner element correctly sealed?
   - Is the correct air cleaner element installed?
     - — If there is any abnormality, clean or replace the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)