CHECK VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0113q2266000


1. Remove the engine cover. (See ENGINE COVER REMOVAL/INSTALLATION [SKYACTIV-D 1.5])

Check valve side



Vacuum pump side

Check valve side



Vacuum dipe side