TURBOCHARGER WITH VARIABLE TURBINE GEOMETRY INSPECTION [SKYACTIV-D 1.5]

id0113q2707600

Compressor wheel inspection

1. Remove the turbocharger with variable turbine geometry. (See TURBOCHARGER WITH VARIABLE TURBINE GEOMETRY REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
2. Visually inspect all of the compressor wheel wings for breakage, damage or bending.
   - If there is bending or damage, replace the variable geometry turbocharger. (See TURBOCHARGER WITH VARIABLE TURBINE GEOMETRY REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)

Note

- If the compressor wheel has contacted the compressor housing, several of the wing ends may have broken, as well as damage or bending may have occurred.
- If there are broken wings, damage or bending in the compressor wheel, verify the following after replacing the variable geometry turbocharger.
  — Intake/exhaust system related parts
  — Oil pipe damage

Turbine wheel inspection

1. Remove the turbocharger with variable turbine geometry. (See TURBOCHARGER WITH VARIABLE TURBINE GEOMETRY REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
2. Visually inspect all of the turbine wheel wings for breakage, damage or bending.
   - If there is bending or damage, replace the variable geometry turbocharger. (See TURBOCHARGER WITH VARIABLE TURBINE GEOMETRY REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)

Note

- If the turbine wheel has contacted the turbine housing, several of the wing ends may have broken, as well as damage or bending may have occurred.
- If there are broken wings, damage or bending in the turbine wheel, verify the following after replacing the variable geometry turbocharger.
  — Intake/exhaust system related parts
  — Oil pipe damage