AIR CLEANER ELEMENT INSPECTION [SKYACTIV-D 1.5]

id0113q2800800

1. Remove the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
2. Inspect the following items:
   - Has the replacement date expired?
   - Is there dirt, damage, or deformity on the air cleaner element?
   - Is the sealing for the air cleaner case and air cleaner element in good condition?
   - Is the correct air cleaner element installed?
     — If there is any malfunction, clean or replace the air cleaner element. (See AIR CLEANER ELEMENT REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)