GLOW PLUG INSPECTION [SKYACTIV-D 1.5]

id0113q2804300

1. Remove the glow plug short-cord. (See GLOW PLUG REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
2. Measure the resistance between the glow plug terminal and the body ground.

Glow plug resistance (specification)
Approx. 1.0 ohms [20 °C {68 °F}]

- If not within the specification, replace the glow plug. (See GLOW PLUG REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)