HIGH PRESSURE FUEL PUMP INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0114q1801500

1. Verify that the fuel pressure sensor is normal. (See FUEL PRESSURE SENSOR INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Connect the M-MDS to the DLC-2.
3. Switch the ignition ON.
4. Select the “FUEL_PRES”, “LOAD” and “RPM” PIDs on the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)

Caution

- **If the engine is run at a high speed, it could be damaged. When racing the engine, be careful not to increase the engine speed suddenly.**

5. Is the “FUEL_PRES” PID value **3.0 MPa {31 kgf/cm^2, 435 psi} or more** while idling.
   — If not as specified, replace the high pressure fuel pump. (See HIGH PRESSURE FUEL PUMP REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)