FUEL PRESSURE RELIEF VALVE INSPECTION [SKYACTIV-D 1.5]


id0114q2706400

Resistance inspection

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)
2. Remove the engine cover. (See ENGINE COVER REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
3. Disconnect the fuel pressure relief valve connector.
4. Inspect the resistance between fuel pressure relief valve terminals A and B.

   Fuel pressure relief valve resistance (specification)
   Approx. 0.47 ohms [20 °C {68 °F}]

   - If not within the specification, replace the common rail. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)



ac5jjw00003532