## FUEL PRESSURE RELIEF VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0114q2706500

**Note**
- The fuel pressure relief valve cannot be removed as it is integrated with the common rail.

1. Remove the common rail. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)