COMMON RAIL INSPECTION [SKYACTIV-D 1.5]

id0114q2803800

Caution
- **It is extremely dangerous to remove the fuel pressure sensor and fuel pressure relief valve from the common rail as it could cause fuel leakage because the common rail is highly pressurized with fuel. Therefore, do not remove the fuel pressure sensor and the fuel pressure relief valve installed to the common rail.**

1. Visually verify that there is no cracking, damage, or rust on the common rail.

Note
- If there is cracking, damage, or rust on the common rail, it could cause fuel leakage.

- If a malfunction is verified, replace the common rail. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)