CHECK VALVE INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0116q1189900

Note
- The check valve cannot be disassembled and inspected because it is integrated with the rollover valve welded to the fuel tank.

1. Perform the fuel tank inspection. (See FUEL TANK INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - If there is any malfunction, replace the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)