CHECK VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0116q2189700

Note
- The check valve cannot be removed because it is integrated with the rollover valve welded to the fuel tank.

1. Remove the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)