ROLLOVER VALVE INSPECTION [SKYACTIV-D 1.5]

id0116q2804500

Note
- The rollover valve cannot be disassembled and inspected as it is built into the fuel tank.

1. Perform the fuel tank inspection. (See FUEL TANK INSPECTION [SKYACTIV-D 1.5].)
   - If there is any malfunction, replace the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)