ROLLOVER VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0116q2804600

Note
- The rollover valve cannot be removed as it is built into the fuel tank.

1. Remove the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)