EVAPORATIVE CHAMBER REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0116q2809800

Note
- The evaporative chamber cannot be removed because it is built into the fuel tank.

1. Remove the fuel tank. (See FUEL TANK REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)