GENERATOR REMOVAL/INSTALLATION [WITHOUT i-ELOOP (SKYACTIV-D 1.5)]


id0117008002j8

Warning

- **Remove and install all parts when the engine is cold, otherwise they can cause severe burns or serious injury.**
- **When the battery cables are connected, touching the vehicle body with generator terminal B will generate sparks. This can cause personal injury, fire, and damage to the electrical components. Always disconnect the negative battery cable before performing the following operation.**


Note

- The i-ELOOP caution label is adhered to the position shown in the figure below on vehicles with i-ELOOP. When determining if a vehicle in for servicing is equipped with i-ELOOP, refer to the i-ELOOP section. (See GENERATOR REMOVAL/INSTALLATION [WITH i-ELOOP (SKYACTIV-D 1.5)].)



am2zzw00012365

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/CONNECTION.)
2. Remove the front under cover No.2. (See FRONT UNDER COVER No.2 REMOVAL/INSTALLATION.)
3. Remove the front splash shield (RH). (See SPLASH SHIELD REMOVAL/INSTALLATION.)
4. Remove the drive belt. (See DRIVE BELT REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
5. Remove the engine cover. (See ENGINE COVER REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
6. Remove in the order indicated in the table.
7. Install in the reverse order of removal.



am2zzw00011496

1	Terminal B cable
2	Generator connector


3	Generator (See Generator Removal Note.) (See Generator Installation Note.)

Generator Removal Note

1. Remove the bolts shown in the figure and set the wiring harness aside.
2. Fully loosen the generator lower bolt and pull it outward until it contacts the body frame.

   Note
   - The generator can be removed without fully removing the lower bolt from the engine.


3. Remove the generator upper bolt.
4. Remove the generator together with the lower bolt from the engine.
5. Remove the generator from above the engine compartment.



am2zzw00012366


Generator Installation Note

1. To facilitate the installation of the generator to the engine, grasp the spacer in the bolt installation hole using pliers and push it down to the nut side.



am2zzw00012367

2. Temporarily install the generator to the engine with the bolt A
3. Align the generator bolt installation holes on the engine and generator sides and temporarily tighten generator installation bolts A and B.
4. Securely tighten the generator installation bolts in the order of A, B.



am2zzw00012368