GENERATOR REMOVAL/INSTALLATION [WITHOUT i-



Generator Installation Note

1. To facilitate the installation of the generator to the engine, grasp the spacer in the bolt installation hole using pliers and push it down to the nut side.