IGNITION COIL INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0118i4800300

SKYACTIV-G 1.5 (with 4-2-1 exhaust system)
Ignition Coil Inspection

1. Perform the spark test and identify the malfunctioning cylinder. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Replace the ignition coil/ion sensor of the malfunctioning cylinder with that of a normal cylinder, and perform the spark test again. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - If the spark is not normal due to a malfunctioning ignition coil/ion sensor, replace that ignition coil/ion sensor. (See IGNITION COIL/ION SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - It is unlikely that all four ignition coil/ion sensors fail to operate properly. To prevent replacing a normal component, perform the above procedure, identify the malfunctioning ignition coil/ion sensor, and replace it.

SKYACTIV-G 1.3, SKYACTIV-G 1.5 (with 4-1 exhaust system)
Ignition Coil Inspection

1. Perform the spark test and identify the malfunctioning cylinder. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Replace the ignition coil of the malfunctioning cylinder with that of a normal cylinder, and perform the spark test again. (See ENGINE CONTROL SYSTEM OPERATION INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - If the spark is not normal due to a malfunctioning ignition coil, replace that ignition coil. (See IGNITION COIL/ION SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - It is unlikely that all four ignition coils fail to operate properly. To prevent replacing a normal component, perform the above procedure, identify the malfunctioning ignition coil, and replace it.