SPARK PLUG REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0118i4800400

Caution
- **If a spark plug that is not as specified is installed, engine performance will be deteriorated. Install only the specified spark plug when replacing.**

1. Disconnect the negative battery cable. (See NEGATIVE BATTERY CABLE DISCONNECTION/ CONNECTION.)
2. Remove the plug hole plate. (See PLUG HOLE PLATE REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
3. Remove the ignition coils/ion sensors. (See IGNITION COIL/ION SENSOR REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
4. Remove the spark plugs using a plug-wrench.
5. Install in the reverse order of removal.

Tightening torque
15—20 N·m {1.6—2.0 kgf·m, 12—14 ft·lbf}