SPARK PLUG INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0118i4800500

Specification

Spark plug type
PE5R-18-110, PE5S-18-110, P51R-18-110

Plug Gap Inspection

Caution
- **To avoid possible damage to the tip, do not adjust the plug gap.**
- **To prevent damaging the tip, use a wire type plug gap gauge when inspecting the plug gap.**

1. Measure the spark plug gap using a wire type plug gap gauge.
   - If not within the standard specification, replace the spark plug.

Spark plug gap
Standard: 1.05—1.40 mm {0.0414—0.0551 in}
New spark plug (reference): 1.05—1.15 mm {0.0414—0.0452 in}

Cleaning


Caution
- **Carbon may adhere to the tip of the spark plug during vehicle delivery or repeated short distance driving during the winter time. If there is any malfunction such as rough idling or start difficulty due to carbon adhesion causing plug fouling, burn off the carbon by performing no-load racing of the engine.**
- **When performing the no-load racing, apply the side brake and foot brake, move the shift lever to neutral (MTX), or the selector lever to P position (ATX) to prevent an accident and serious injury.**
- **To avoid possible damage to the spark plug tip, do not use a wire brush for cleaning.**

Note
- To avoid possible damage to the tip, use gasoline to clean the spark plugs after removing dirt.
- If the accelerator pedal is depressed continuously for a specified time, the engine speed may decrease to the idle speed. This is due to the PCM control operation, which prevents overheating, and it does not indicate a malfunction.
- Do not perform no-load racing at high engine speed continuously for **10 s or more**.

1. If there is carbon adhering to the spark plug, perform no-load racing at **4,000 rpm** for **2 min**, **2 times**.

Visual Inspection

1. Inspect the following items:
   - If any of the following malfunctions are indicated, replace the spark plug.
     — Insulator breakage
     — Worn electrode
     — Damaged gasket
     — Badly burned insulator (sparking side)




am3uuw00006241

Resistance Inspection

1. Measure the resistance of the spark plug using a ohmmeter as shown in the figure.
   - If not within specification, replace the spark plug.

   Spark plug resistance [25°C {77 °F}]
   3.0—7.5 kilohms



am3uuw00006245