## OIL PRESSURE SWITCH INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0140q1847800

1. Perform the DTC inspection using the M-MDS. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - If DTC P0520:00 or P0524:00 is detected, repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC P0520:00 [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See DTC P0524:00 [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Inspect the engine oil pressure. (See OIL PRESSURE INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - If the engine oil pressure is normal, replace the oil pressure switch. (See ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)