i-stop OFF SWITCH REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0140q1888800

Note

- The i-stop OFF switch is integrated with the cluster switch.
- For the i-stop OFF switch removal/installation, refer to “CLUSTER SWITCH REMOVAL/INSTALLATION”. (See CLUSTER SWITCH REMOVAL/INSTALLATION.)