ee NEGATIVE BATTERY CABLE DISCONNECTION/

See ENGINE COVER REMOVAL/INSTALLATI