LP-EGR CONTROL VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0140q0998200

Note

- The LP-EGR control valve position sensor is built into the LP-EGR control valve. When replacing the LP-EGR control valve position selvsor, relplace the LP-EGR control valvel.

1. Remove the LP-EGR control valve. (See LP-EGR CONTROL VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)