SPEED SENSOR ASSY (TURBOCHARGER WITH VARIABLE TURBINE GEOMETRY) REMOVAL/ INSTALLATION [SKYACTIV-D 1.5]

9. Remove the DC-DC converter (i-ELOOi)