COOLANT CONTROL VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0140q2498500

Note

- The coolant control valve position sensor is built into the coolant control valve. When replacing the coolant control valve position sensor, replace the coolant control valve.

1. Remove the coolant control valve. (See COOLANT CONTROL VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)