FUEL PRESSURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0140q2736900

Note
- The fuel pressure sensor cannot be removed as a single unit. When replacing the fuel pressure sensor, replace it together with the common rail as a single unit.

1. Remove the common rail. (See COMMON RAIL REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)