FUEL TEMPERATURE SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0140q2806500

Note
- The fuel temperature sensor cannot be removed as a single unit. When replacing the fuel temperature sensor, replace it together with the lower case as a single unit.

1. Remove the lower case. (See LOWER CASE REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)