
i-stop WARNING ALARM [SKYACTIV-D 1.5]

id0140z5300500

Purpose
- The i-stop warning alarm alerts the driver that the driver-side door is open or the engine stalls while the engine is stopped by i-stop control.


Function
- When the instrument cluster receives the i-stop warning alarm request signal sent from the PCM via the CAN signal, the i-stop warning alarm sounds.
- The i-stop warning alarm sound pattern is as shown in the figure.



ac5wzn00001422

Construction
- The i-stop warning alarm sounds using the buzzer built into the instrument cluster.

Operation
1. The instrument cluster receives (1) the i-stop warning alarm request signal from the PCM.
2. The instrument cluster microcomputer turns the transistor on (2) based on the i-stop warning alarm request signal.
3. When the transistor turns on, a ground circuit with the alarm is established and the alarm sounds (3).



am2zzn00003716

Fail-safe
- Not applicable