## NO.1 TPMS WARNING LIGHT ILLUMINATES [TIRE PRESSURE MONITORING SYSTEM (TPMS)]

id020304101000

**Caution**

- **The Tire Pressure Monitoring System (TPMS) warning light illuminates according to the decrease in a tire air pressure (TPMS is normal).**
- **The No.1 TPMS WARNING LIGHT ILLUMINATES the diagnostic procedure if the TPMS warning light illuminated due to a decrease in a tire pressure although the TPMS is normal.**

**Possible malfunction**

- The air pressure of a tire has decreased. (TPMS is normal)

**Diagnostic Procedure**

| Step | Inspection | Results | Action |
|---|---|---|---|
| 1 | **TIRE PRESSURE INSPECTION**<br>• Inspect tire pressures while the tires are cold. (See WHEEL AND TIRE SPECIFICATION.)<br>• Are the tire pressures at the specification? | Yes | Go to the next step. |
| | | No | Adjust the tire pressures to the specification while the tires are cold. |
| 2 | **TIRE PRESSURE MONITORING SYSTEM INITIALIZATION**<br>• Perform tire pressure monitoring system initialization.<br>• Connect the M-MDS to DLC-2.<br>• After the vehicle is identified, select the following items from the initial screen of the IDS.<br>1. Select "Chassis"<br>2. Select "ABS/DSC"<br>3. Select "TPMS Reset"<br>• Was the tire pressure monitoring system initialization performed? | Yes | Go to the next step. |
| | | No | Perform the tire pressure monitoring system initialization. |
| 3 | **TPMS WARNING LIGHT VERIFICATION**<br>• Drive the vehicle for several minutes after the TPMS warning light turns off.<br>• Does the TPMS warning light illuminate? | Yes | Inspect the tires and wheels for air leakage. |
| | | No | The tire pressure monitoring system is normal. |