REAR WHEEL ALIGNMENT

id021100800300

Rear wheel alignment (Unloaded)*1

Item				Fuel gauge indication				
				Empty	1/4	1/2	3/4	Full
Total toe-in	Tire [Tolerance ±5 {0.2}]	Normal ground clearance*3	(mm {in})	4.3 {0.169}				
		High ground clearance*4		3.2 {0.126}				
	Rim inner [Tolerance ±4 {0.2}]	Normal ground clearance*3		Vehicle equipped with 15 inch wheel: 2.6 {0.102} Vehicle equipped with 16 inch wheel: 2.8 {0.110}				
		High ground clearance*4		Vehicle equipped with 15 inch wheel: 2.0 {0.079} Vehicle equipped with 16 inch wheel: 2.1 {0.083}				
	(degree)	Normal ground clearance*3		0°24′±0°22′				
		High ground clearance*4		0°18′±0°22′				
Camber angle*2 (Reference value) [Tolerance ±1°]		Normal ground clearance*3		-1°28′	-1°28′	-1°29′	-1°29′	-1°29′
		High ground clearance*4		-1°26′	-1°26′	-1°27′	-1°27′	-1°27′
Thrust angle (Reference value) [Tolerance ±0°48′]				0°00′				

*1 : Engine coolant and engine oil are at specified level. Spare tire, jack and tools are in designated position.

*2 : Difference between left and right must not exceed 1°30′.

*3 : Distance between wheel center and fender brim is 381 mm {15.0 in} (reference value).

*4 : Distance between wheel center and fender brim is 401 mm {15.8 in} (reference value).