DTC U2101:00/U2300:52/U2300:54/U2300:55/U2300:56/U2300:64 [ABS HU/CM]

id040260862800

DTC	**U2101:00** **U2300:52** **U2300:54** **U2300:55** **U2300:56** **U2300:64**	**ABS HU/CM configuration**
DETECTION CONDITION		• ABS CM detects configuration data not record or data error
FAIL-SAFE FUNCTION		Refer to DTC TABLE. (See DTC TABLE [ABS HU/CM].)
POSSIBLE CAUSE		• Configuration procedure is not done properly • Correct data cannot be received from instrument cluster • Another vehicles control modules been installed
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**RECORD CONFIGURATION DATA** • Switch the ignition OFF. • Switch the ignition ON (engine off), and maintain this condition for **approx. 10 s or more**. • Switch the ignition OFF, and maintain this condition for **approx. 3 s or more**. • Switch the ignition ON (engine off), and maintain this condition for **approx. 3 s or more**.		Go to the next step.
2	**VERIFY ABS HU/CM DTC** • Using the M-MDS, clear the DTC from the ABS HU/CM. (See CLEARING DTC [ABS HU/CM].) • Using the M-MDS, perform the ABS HU/CM DTC inspection. (See DTC INSPECTION [ABS HU/CM].) • Are any DTCs present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, go to the next step.
		No	Go to Step6.
3	**VERIFY IF PARTS FROM ANOTHER VEHICLE INSTALLED TO INSTRUMENT CLUSTER, PCM OR ABS HU/CM** • Verify if an instrument cluster, PCM or ABS HU/CM from another vehicle is installed. • Has an instrument cluster, PCM, ABS HU/CM or other vehicle part been installed to vehicle?	Yes	Install the correct instrument cluster, PCM or ABS HU/CM, then go to Step1. (See INSTRUMENT CLUSTER REMOVAL/INSTALLATION.) (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See ABS HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See ABS HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		No	Go to the next step.
4	**VERIFY INSTRUMENT CLUSTER AND PCM DTC** • Using the M-MDS, perform the instrument cluster and PCM DTC inspection. (See DTC INSPECTION [INSTRUMENT CLUSTER].) (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [INSTRUMENT CLUSTER].) (See DTC TABLE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) DTC troubleshooting completed, then go to the next step.
		No	Go to the next step.
5	**VERIFY ABS HU/CM DTC** • Using the M-MDS, clear the DTC from the ABS HU/CM. (See CLEARING DTC [ABS HU/CM].) • Using the M-MDS, perform the ABS HU/CM DTC inspection. (See DTC INSPECTION [ABS HU/CM].) • Are any DTCs present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, replace the ABS HU/CM, then go to the next step. (See ABS HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See ABS HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		No	Go to the next step.
6	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [ABS HU/CM].)
		No	DTC troubleshooting completed.