DTC C0010:01/C0011:01/C0014:01/C0015:01/C0018:01/C0019:01/C001C:01/C001D:01 [ABS HU/CM]

id0402608772000

DTC	**C0010:01**	**ABS HU/CM internal malfunction (LF inlet solenoid valve)**
	C0011:01	**ABS HU/CM internal malfunction (LF outlet solenoid valve)**
	C0014:01	**ABS HU/CM internal malfunction (RF inlet solenoid valve)**
	C0015:01	**ABS HU/CM internal malfunction (RF outlet solenoid valve)**
	C0018:01	**ABS HU/CM internal malfunction (LR inlet solenoid valve)**
	C0019:01	**ABS HU/CM internal malfunction (LR outlet solenoid valve)**
	C001C:01	**ABS HU/CM internal malfunction (RR inlet solenoid valve)**
	C001D:01	**ABS HU/CM internal malfunction (RR outlet solenoid valve)**
DETECTION CONDITION		• Malfunction detected in the ABS HU/CM solenoid valve or internal circuit by the ABS HU/CM on-board diagnostic function
FAIL-SAFE FUNCTION		Refer to DTC TABLE. (See DTC TABLE [ABS HU/CM].)
POSSIBLE CAUSE		• Solenoid valve in ABS HU/CM malfunction • Solenoid valve internal circuit in ABS HU/CM malfunction
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY SOLENOID VALVE OPERATION** • Using the M-MDS, perform the simulation inspection for solenoid valve. (See SIMULATION INSPECTION [ABS HU/CM].) • Does the solenoid valve operate?	Yes	Go to the next step.
		No	Replace the ABS HU/CM, then go to the next step. (See ABS HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See ABS HU/CM REMOVAL/INSTALLATION [R.H.D.].)
2	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Using the M-MDS, clear the DTC from the ABS HU/CM. (See CLEARING DTC [ABS HU/CM].) • Start the engine and drive the vehicle at 6 km/h {4 mph} or more. • Gradually slow down and stop vehicle. • Using the M-MDS, perform the ABS HU/CM DTC inspection. (See DTC INSPECTION [ABS HU/CM].) • Is the same DTC present?	Yes	Repeat the inspection from Step1. If the malfunction recurs, replace the ABS HU/CM, then go to the next step. (See ABS HU/CM REMOVAL/INSTALLATION [L.H.D.].) (See ABS HU/CM REMOVAL/INSTALLATION [R.H.D.].)
		No	Go to the next step.
3	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [ABS HU/CM].)
		No	DTC troubleshooting completed.