DTC U0402:00 [ABS HU/CM]

id040260881800

DTC	U0402:00	Signal error from transmission/transaxle
DETECTION CONDITION		• The ABS HU/CM received error signals from the transmission/transaxle for 1 s or more with the ignition switched ON (engine off or on)
FAIL-SAFE FUNCTION		Refer to DTC TABLE. (See DTC TABLE [ABS HU/CM].)
POSSIBLE CAUSE		• The transmission/transaxle could not send a normal signal temporarily (DTCs are stored in the TCM) • Transmission/transaxle malfunction • ABS HU/CM malfunction
SYSTEM WIRING DIAGRAM		—

Diagnostic Procedure

Step	Inspection		Action
1	**VERIFY TCM DTC** • Using the M-MDS, perform the TCM DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC INSPECTION [TCM (CW6A-EL)].) • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See ON-BOARD DIAGNOSTIC SYSTEM DTC TABLE [TCM (CW6A-EL)].) DTC troubleshooting completed, then go to the next step.
		No	Go to the next step.
2	**VERIFY DTC TROUBLESHOOTING COMPLETED** • Using the M-MDS, clear the DTC from the ABS HU/CM. (See CLEARING DTC [ABS HU/CM].) • Using the M-MDS, perform the ABS HU/CM DTC inspection. (See DTC INSPECTION [ABS HU/CM].) • Is the same DTC present?	Yes	Repeat the inspection from Step1 If the malfunction recurs, replace the TCM, then go to the next step. (See CONTROL VALVE BODY REMOVAL/ INSTALLATION [CW6A-EL].)
		No	Go to the next step.
3	**VERIFY NO DTC IS PRESENT** • Are any DTCs present?	Yes	Go to applicable DTC inspection. (See DTC TABLE [ABS HU/CM].)
		No	DTC troubleshooting completed.