CLEARING DTC [ABS HU/CM]

id040260985100

CMDTC clearing DTCs procedure

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “All CMDTCs”.
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition OFF.
6. Switch the ignition ON (engine off) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [ABS HU/CM].)
8. Verify that no DTCs are displayed.

ODDTC clearing DTCs procedure

1. Connect the M-MDS to the DLC-2.
2. After the vehicle is identified, select the following items from the initialization screen of the M-MDS.
   (1) Select “Self Test”.
   (2) Select “Modules”.
   (3) Select “ABS”.
3. Verify the DTC according to the directions on the screen.
4. Press the clear button on the DTC screen to clear the DTC.
5. Switch the ignition OFF.
6. Switch the ignition ON (engine off) and wait for **5 s or more**.
7. Perform DTC inspection. (See DTC INSPECTION [ABS HU/CM].)
8. Verify that no DTCs are displayed.