DTC TABLE [ABS HU/CM]

id040260985200

×: Applicable
—: Not applicable

DTC	ABS warning light	Brake system warning light (when parking brake is released)	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
C0010:01 C0011:01 C0014:01 C0015:01 C0018:01 C0019:01 C001C:01 C001D:01	Illuminates	Illuminates	ABS HU/CM internal malfunction (solenoid valve system)	×	—	C, D	×	(See DTC C0010:01/ C0011:01/ C0014:01/ C0015:01/ C0018:01/ C0019:01/C001C: 01/C001D:01 [ABS HU/CM].)
C0020:11 C0020:12 C0020:13 C0020:71	Illuminates	Not illuminate	Pump motor, motor relay	×	—	C, D	×	(See DTC C0020:11/ C0020:12/ C0020:13/ C0020:71 [ABS HU/ CM].)
C0030:07	Illuminates	Not illuminate*2	LF ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/C003A: 07/C003A:29/ C003A:2F/C003A: 64 [ABS HU/CM].)
C0031:07			LF ABS wheel-speed sensor/ABS sensor rotor					
C0031:11 C0031:15	Illuminates	Not illuminate*2	LF ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/C003A: 11/C003A:15 [ABS HU/CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
C0031:29 C0031:2F C0031:64	Illuminates	Not illuminate*2	LF ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/C003A:07/C003A:29/ C003A:2F/C003A:64 [ABS HU/CM].)
C0033:07	Illuminates	Not illuminate*2	RF ABS sensor rotor	×	—	C, D	×	
C0034:07			RF ABS wheel-speed sensor/ABS sensor rotor					
C0034:11 C0034:15	Illuminates	Not illuminate*2	RF ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/C003A:11/C003A:15 [ABS HU/CM].)
C0034:29 C0034:2F C0034:64	Illuminates	Not illuminate*2	RF ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/C003A:07/C003A:29/ C003A:2F/C003A:64 [ABS HU/CM].)
C0036:07	Illuminates	Not illuminate*2	LR ABS sensor rotor	×	—	C, D	×	
C0037:07			LR ABS wheel-speed sensor/ABS sensor rotor					
C0037:11 C0037:15	Illuminates	Not illuminate*2	LR ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/C003A:11/C003A:15 [ABS HU/CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
C0037:29 C0037:2F C0037:64	Illuminates	Not illuminate*2	LR ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/C003A:07/C003A:29/ C003A:2F/C003A:64 [ABS HU/CM].)
C0039:07	Illuminates	Not illuminate*2	RR ABS sensor rotor	×	—	C, D	×	
C003A:07			RR ABS wheel-speed sensor/ABS sensor rotor					
C003A:11 C003A:15	Illuminates	Not illuminate*2	RR ABS wheel-speed sensor	×	—	C, D	×	(See DTC C0031:11/ C0031:15/ C0034:11/ C0034:15/ C0037:11/ C0037:15/C003A:11/C003A:15 [ABS HU/CM].)
C003A:29 C003A:2F C003A:64	Illuminates	Not illuminate*2	RR ABS wheel-speed sensor/ABS sensor rotor	×	—	C, D	×	(See DTC C0030:07/ C0031:07/ C0031:29/ C0031:2F/ C0031:64/ C0033:07/ C0034:07/ C0034:29/ C0034:2F/ C0034:64/ C0036:07/ C0037:07/ C0037:29/ C0037:2F/ C0037:64/ C0039:07/C003A:07/C003A:29/ C003A:2F/C003A:64 [ABS HU/CM].)
C0040:64	Not illuminate	Not illuminate	Brake switch	×	—	C, D	×	(See DTC C0040:64 [ABS HU/CM].)
C0061:54	Not illuminate	Not illuminate	ABS HU/CM (unperformed initialization procedure)	×	—	C, D	×	(See DTC C0061:54/ C0062:54 [ABS HU/CM].)

DTC	ABS warning light	Brake system warning light (when parking brake is released)	Description	Fail-safe	Drive cycle	Self test type*1	Memory function	Page
C0062:28	Not illuminate	Not illuminate	SAS control module	×	—	C, D	×	(See DTC C0062:28/ C0062:64 [ABS HU/ CM].)
C0062:54	Not illuminate	Not illuminate	ABS HU/CM (unperformed initialization procedure)	×	—	C, D	×	(See DTC C0061:54/ C0062:54 [ABS HU/ CM].)
C0062:64	Not illuminate	Not illuminate	SAS control module	×	—	C, D	×	(See DTC C0062:28/ C0062:64 [ABS HU/ CM].)
C0062:76	Not illuminate	Not illuminate	SAS control module	×	—	C, D	×	(See DTC C0062:76 [ABS HU/ CM].)
U0001:88	Illuminates	Not illuminate	CAN line	×	—	C, D	×	(See DTC U0001:88/ U0100:00/ U0101:00/ U0151:00/ U0155:00 [ABS HU/ CM].)
U0100:00	Illuminates*3	Not illuminate						
U0101:00	Not illuminate	Not illuminate						
U0151:00	Not illuminate	Not illuminate						
U0155:00	Illuminates*3	Not illuminate						
U0401:00	Not illuminate	Not illuminate	Signal error from PCM	×	—	C, D	×	(See DTC U0401:00 [ABS HU/ CM].)
U0402:00	Not illuminate	Not illuminate	Signal error from transmission/ transaxle	×	—	C, D	×	(See DTC U0402:00 [ABS HU/ CM].)
U0423:00	Not illuminate	Not illuminate	Signal error from instrument cluster	×	—	C, D	×	(See DTC U0423:00 [ABS HU/ CM].)
U0452:86	Not illuminate	Not illuminate	Signal error from SAS control module	×	—	C, D	×	(See DTC U0452:86 [ABS HU/ CM].)
U2101:00	Illuminates	Not illuminate	ABS HU/CM configuration	×	—	C, D	×	(See DTC U2101:00/ U2300:52/ U2300:54/ U2300:55/ U2300:56/ U2300:64 [ABS HU/ CM].)
U2300:52								
U2300:54								
U2300:55								
U2300:56								
U2300:64								
U3000:49	Illuminates	Illuminates*3	ABS HU/CM internal malfunction	×	—	C, D	×	(See DTC U3000:49 [ABS HU/ CM].)
U3003:16	Illuminates	Not illuminate*4	Battery power supply	×	—	C, D	×	(See DTC U3003:16/ U3003:17 [ABS HU/ CM].)
		Illuminates*5*6						
U3003:17	Illuminates	Illuminates						

*1 : C: CMDTC self test, D: ODDTC self test
*2 : Illuminates when two wheels or more have a malfunction

*3 : Not illuminate depending on malfunction content
*4 : When power supply voltage is 8.4—9.6 V for 0.7 s or more
*5 : When power supply voltage is 6.0—8.4 V for 0.8 s or more
*6 : When power supply voltage is 6 V or less for 0.05 s or more

Fail-safe function table

×: Control enabled
—: Control disabled

DTC	ABS control	EBD control
C0010:01	—	—
C0011:01		
C0014:01		
C0015:01		
C0018:01		
C0019:01		
C001C:01		
C001D:01		
C0020:11	—	×
C0020:12		
C0020:13		
C0020:71		
C0030:07	—	×*1
C0031:07		
C0031:11		
C0031:15		
C0031:29		
C0031:2F		
C0031:64		
C0033:07	—	×*1
C0034:07		
C0034:11		
C0034:15		
C0034:29		
C0034:2F		
C0034:64		
C0036:07	—	×*1
C0037:07		
C0037:11		
C0037:15		
C0037:29		
C0037:2F		
C0037:64		
C0039:07	—	×*1
C003A:07		
C003A:11		
C003A:15		
C003A:29		
C003A:2F		
C003A:64		
C0040:64	×	×
C0061:54	×	×
C0061:64	×	×
C0062:28	×	×
C0062:54		
C0062:64		
C0062:76		
U0001:88	—	×
U0100:00	—*2	×
U0101:00	×	×
U0151:00	×	×
U0155:00	—*2	×

DTC	ABS control	EBD control
U0401:00	×	×
U0402:00	×	×
U0423:00	×	×
U0452:86	×	×
U2101:00	—	×
U2300:52		
U2300:54		
U2300:55		
U2300:56		
U2300:64		
U3000:49	—	—*2
U3003:16	—	×*3
		—*4*5
U3003:17	—	—

*1 : Control disabled when two wheels or more have a malfunction
*2 : Enabled depending on malfunction content
*3 : When power supply voltage is 8.4—9.6 V for 0.7 s or more
*4 : When power supply voltage is 6.0—8.4 V for 0.8 s or more
*5 : When power supply voltage is 6 V or less for 0.05 s or more