## DTC U0420:00 [DSC HU/CM]

id040262861800

| DTC | U0420:00 | Signal error from EPS control module |
|---|---|---|
| DETECTION CONDITION | | • Error detected in signal from EPS control module via CAN communication |
| FAIL-SAFE FUNCTION | | Refer to DTC TABLE. (See DTC TABLE [DSC HU/CM].) |
| POSSIBLE CAUSE | | • EPS control module malfunction |
| SYSTEM WIRING DIAGRAM | | — |

### Diagnostic Procedure

| Step | Inspection | | Action |
|---|---|---|---|
| 1 | **VERIFY EPS CONTROL MODULE DTC**<br>• Using the M-MDS, perform the EPS control module DTC inspection.<br>(See DTC INSPECTION [EPS CONTROL MODULE].)<br>• Are any DTCs present? | Yes | Go to applicable DTC inspection.<br>(See DTC TABLE [EPS CONTROL MODULE].)<br>DTC troubleshooting completed, then go to the next step. |
| | | No | Go to the next step. |
| 2 | **VERIFY DTC TROUBLESHOOTING COMPLETED**<br>• Using the M-MDS, clear the DTC from the DSC HU/CM.<br>(See CLEARING DTC [DSC HU/CM].)<br>• Using the M-MDS, perform the DSC HU/CM DTC inspection.<br>(See DTC INSPECTION [DSC HU/CM].)<br>• Is the same DTC present? | Yes | Repeat the inspection from Step1<br>If the malfunction recurs, replace the steering column, then go to the next step.<br>(See STEERING WHEEL AND COLUMN REMOVAL/ INSTALLATION.) |
| | | No | Go to the next step. |
| 3 | **VERIFY NO DTC IS PRESENT**<br>• Are any DTCs present? | Yes | Go to applicable DTC inspection.<br>(See DTC TABLE [DSC HU/CM].) |
| | | No | DTC troubleshooting completed. |